




ASSEMBLY INSTRUCTIONS


ALL-SURFACE SOCCER TENNIS NET SA-T550

Before beginning assembly, please unpack and inspect all parts for completeness and for any possible damage that may have occurred during delivery. If any damage has occurred, please contact Customer Support at 888-887-2867.


PARTS & ACCESSORIES




BASE X 2




MIDDLE POLE X 1




SIDE POLE X 2



NET X 1









BAG X 1



GROUND STAKES X 4

Note: For natural grass field/ ground soil use only.



CONSUMER PRODUCT SAFETY ALERT

All sports equipment must be anchored and/or counterbalanced at all times. Sports equipment not in use must be disassembled and stored in a secure area. Do not use this equipment during high winds or storms. Routine inspection of this equipment for quality and safety is recommended. Any modification to this or any AGORA products will void any and all warranties or return requests.