



NORMAL MODE (Default)

- In *Normal Mode*, Day / Hours / Minutes / Seconds are displayed.
 - Press and hold S3 to view *Date*.
 - Press and hold S1 to view *Alarm Time*.
 - Press and hold S1, then simultaneously press S3 to turn *Alarm ON / OFF*.
- Note: Alarm indicator icon will appear when Alarm is ON.**

STOPWATCH MODE

To access, press S2 once from Normal Mode. When *Stopwatch Mode* is displayed, SU-FR-SA (days of the week) will flash.

ELAPSED TIMER

1. Press S3 to Start (SU-SA flash).
2. Press S3 to Stop (SU-FR-SA flash).
3. Press S1 to Restart.
4. Press S2 to return to Normal Mode.

SPLIT TIMER (3 OR MORE COMPETITORS)

1. Press S3 to Start (SU-SA flash).
2. Press S1 to display First Time (SU-TH-SA flash).
Note: Repeat steps 1 and 2 for Additional Times.
3. Press S3 to Stop Timing (SU-FR-SA flash).
4. Press S1 twice to reset to zero.
5. Press S2 to return to Normal Mode.

TWO-COMPETITOR TIMER

1. Press S3 to Start (SU-SA flash)
2. Press S1 to display First Time (SU-TH-SA flash).
3. Press S3 to Stop Timing (SU-TH-FR flash).
4. Press S1 to display Second Time (SU-FR-SA flash).
5. Press S1 again to reset to zero.
6. Press S2 to return to Normal Mode.

NOTE: Both S2 buttons hold the same function.

Battery Replacement

Batteries should be replaced when the screen darkens or nothing is displayed. Use a screwdriver to remove the back cover.

Reminders

This Stopwatch is water resistant, not waterproof. Do not leave in direct sunlight for extended periods of time. Avoid contact with corrosive substances and avoid using it in weather conditions of extreme cold or extreme heat.

SETTING DATE AND TIME

1. To access settings, press S2 three times from Normal Mode.
2. Press S1 to scroll through Seconds, Minutes, Hour, Date.
3. Flashing digit indicates area ready for adjustment.
4. Press S3 to adjust flashing digit.
5. Press S2 to set and return to Normal Mode.

Additional Notes:

- Press and hold S3 for faster adjustment
- Seconds can only be set to 00.
- Hour digits will scroll through AM, PM, and H (24-hr clock).

SETTING ALARM TIME

- To access settings, press S2 twice from Normal Mode, then:
1. Press S1 to select Hours or Minutes.
 2. Press S3 to adjust area currently blinking.
 3. Press S2 to save Alarm Time.

Additional Notes:

- Press and hold S3 for faster adjustment.
- Alarm Time can only reflect AM or PM, not a 24-hr clock.
- Adjusting Alarm Time activates it (indicator icon appears).
- See *NORMAL MODE* instructions to turn Alarm ON / OFF.

ALARM SILENCE / SNOOZE

When Alarm sounds:

- Press S1 to end / silence Alarm (no snooze).
- Press S3 to activate 5-minute snooze period.

HOURLY CHIME (stopwatch beeps at the top of each hour)

To turn Hour Chime ON / OFF, press and hold S1 and press S2.

- When ALL days of the week appear: ON
- When ALL days of the week disappear: OFF