




# AGORA SOCCER TENNIS NET (SA-T500)



## Parts List:

- A. Anchor Post (2)
- B. Soccer Tennis Net (1)
- C. Guy Ropes (2)
- D. Tension Plate (2)
- E. Ground Pegs (4)
- F. Net Pouch (1)
- G. Carry Bag (1)




1. Slide anchor post (A) into sleeves on soccer tennis net (B).

STEP 1


**NOTE:** If Guy Ropes are already pre-assembled to Soccer Tennis Net skip to STEP #5

2. Feed one end of the guy rope (C) through the hole in ground peg (E) and tension plate (D). Tie a knot at the rope's end. Repeat this step for the other rope end.

3. Locate center length of rope and pass it through the grommets at the top of the soccer tennis net. Pass the ground pegs through the formed loop and pull securely.



STEP 2



STEP 3


4. Repeat Steps # 2 and 3 on the other side of the soccer tennis net.

5. Anchor soccer tennis net in the desired location by pushing anchor post bases into the ground using only foot pressure.

**NOTE:** Do not use a hammer, it may cause damage to the base.

6. Anchor ground pegs approximately 48" from the anchor post base.

7. Once all four ground pegs are securely anchored, adjust tension of the guy ropes using the tension plates.



## CONSUMER PRODUCT SAFETY ALERT

Goals can tip over and cause injury when not properly anchored!

**SAFETY SUGGESTIONS / GUIDELINES:** Secure anchor goals at all times. Never climb on the net or goal framework.

Disassemble and safely store goals when not in use. Inspect hardware and nets before every use. Replace damage or missing parts immediately. Do not leave assembled goal unattended. Instruct players on the safe handling of and potential danger associated with the goal.

